

GF-14 Fan Replacement Motor Instructions



1. Open the electrical box and unplug the black wires on the thermostat and cut off the connectors.
2. Pull the intake grill of the bottom of the GF-14 Fan. Unscrew the nuts holding the fan to the cross support. Pull the black wires out and lift the fan/motor out from the top.
3. Use an allen wrench to remove the fan blade from the motor shaft. Reinstall the blade on the replacement motor.

Mount the new motor on the cross support and **DO NOT over tighten the nuts** or you will pull the studs out of the motor and void the warranty.

4. Push the wires back through the hole and attach the connectors and connect the thermostat.
5. Return the motor to us in the supplied box.

Thank you for your business.